







E69(A), E70(B), E71(C), E72(D), E73(E), E74(F), f1(G)  
Radio Receiver Assembly





M29(A), M30(B), M31(C), M32(D), g1(E)  
Stereo Component Amplifier




- \* 1 : 14 Speaker
- \* 2 : 8 Speaker
- \* 3 : w/ Bluetooth w/o LEXUS Navigation System
- \* 4 : w/ LEXUS Navigation System
- \* 6 : w/ DVD Changer








- \* 3 : w/ Bluetooth w/o LEXUS Navigation System
- \* 4 : w/ LEXUS Navigation System
- \* 5 : w/ Bluetooth
- \* 6 : w/ DVD Changer
- \* 7 : w/o DVD Changer
- \* 8 : w/ Rear View Monitor











A 32  
White



A 36  
Black




B 36  
Gray




E 10  
White




E 19  
White




E 20  
White




E 21  
Black




E 30  
Black




E 31  
Gray




E 34  
Blue




E 35  
Blue




E 37  
White




E 42  
White




E 44  
White




E 46  
White




E 48  
White




E 62  
White




E 63  
White




E 64  
Blue




E 69  
White




E 70  
White




E 71  
Blue



E 72  
White




E 73  
White




E 74  
White




E 86  
White




E 87  
White




E 91  
Black




E 92  
Black




E 94  
White




E 95  
White




F 4  
Gray



G 2  
White



H 8  
White



I 7  
White



J 5  
Gray




(8 Speaker)

J 5  
White



(14 Speaker)

J 6  
White



K 5  
Gray




(8 Speaker)

K 5  
White




(14 Speaker)


K 6  
White




M 11  
Blue



























M 26  
White




M 27  
White






4J

Gray




4L

Gray




4M

White




DC

White




DD

White




DF

White




DG

White




DH

White




DM

White




AE1

Gray



AE3


White



BA2


Black

White




EA1

White




EF1


White




EM3  
White




EQ1  
White




GE1  
White




HE1  
White




IE1  
White



JM1  
White





KL1  
White




LM1  
White

LR1  
White



MA1  
Black



ME1  
Blue

fg1  
Blue

