






E69(A), E70(B), E71(C), E72(D), E73(E), E74(F), f1(G)
Radio Receiver Assembly





M29(A), M30(B), M31(C), M32(D), g1(E)
Stereo Component Amplifier




- * 1 : 14 Speaker
- * 2 : 8 Speaker
- * 3 : w/ Bluetooth w/o LEXUS Navigation System
- * 4 : w/ LEXUS Navigation System
- * 6 : w/ DVD Changer









- * 3 : w/ Bluetooth w/o LEXUS Navigation System
- * 4 : w/ LEXUS Navigation System
- * 5 : w/ Bluetooth
- * 6 : w/ DVD Changer
- * 7 : w/o DVD Changer
- * 8 : w/ Rear View Monitor









A 32
White



A 36
Black




B 36
Gray




E 10
White




E 19
White




E 20
White




E 21
Black




E 30
Black




E 31
Gray




E 34
Blue




E 35
Blue




E 37
White




E 42
White




E 44
White




E 46
White




E 48
White




E 62
White




E 63
White




E 64
Blue




E 69
White




E 70
White




E 71
Blue



E 72
White




E 73
White




E 74
White




E 86
White




E 87
White




E 91
Black




E 92
Black




E 94
White




E 95
White




F 4
Gray



G 2
White



H 8
White



I 7
White



J 5
Gray




(8 Speaker)

J 5
White



(14 Speaker)

J 6
White



K 5
Gray




(8 Speaker)

K 5
White




(14 Speaker)


K 6
White




M 11
Blue




M 26
White




M 27
White



























(8 Speaker)




(14 Speaker)




4J

Gray




4L

Gray




4M

White




DC

White




DD

White




DF

White




DG

White




DH

White




DM

White




AE1

Gray



AE3


White



BA2


Black

White




EA1

White




EF1


White




EM3
White




EQ1
White




GE1
White




HE1
White




IE1
White



JM1
White





KL1
White




LM1
White

LR1
White



MA1
Black



ME1
Blue

fg1
Blue

