





FROM POWER SOURCE SYSTEM (SEE PAGE 72)






* 1 : W/ DOOR CLOSER




FROM POWER SOURCE SYSTEM (SEE PAGE 72)



FROM POWER SOURCE SYSTEM (SEE PAGE 72)

* 1 : W/ DOOR CLOSER
 * 2 : W/O DOOR CLOSER



SYSTEM OUTLINE

In this system, the door lock control receiver receives weak radio wave transmitted from the transmitter built-into the ignition key and outputs the signal to the theft deterrent ECU. Through communication control of the theft deterrent ECU and door ECU etc. , all the doors and the luggage door can be locked and unlocked by the remote control.

1. NORMAL OPERATION

* Lock operation

When the lock SW on the transmitter is pressed, all the doors are locked.

* Unlock operation

When the unlock SW on the transmitter is pressed once, only the driver door is unlocked. When the unlock SW is pressed again within 3 sec., all the doors are unlocked.

* Luggage door unlock operation

When the luggage door unlock SW is kept pressed for approximately 1.0 sec. or longer, the luggage door is opened.

2. AUTO LOCK FUNCTION

If the door is not actually opened within 30 sec. after the door has been unlocked by pressing the unlock SW on the transmitter, all the doors are automatically locked. If any of the following conditions is detected, the auto lock does not function.

Any door is opened.

The ignition key is inserted into the ignition SW.

When the lock detection SW of all the doors are locked.

3. WIRELESS DOOR LOCK STOP FUNCTION

If any of the following conditions is detected, the wireless door lock does not function.

* Lock operation

Any door is open (The door courtesy SW is on).

The ignition key is inserted into the ignition key cylinder (The unlock warning SW is on).

The ignition SW is turned to the ON position.

* Unlock operation

The ignition SW is turned to ON position.

* Luggage door unlock operation

The ignition SW is turned to ON position.

4. ANSER BACK FUNCTION

* When the doors are locked by wireless operation, the buzzer sounds once and the hazard lights blink once.

* When the doors are unlocked by wireless operation, the buzzer sounds twice and hazard lights blink twice.

* When the luggage door is unlocked by wireless operation, the buzzer sounds once.

* When the doors are locked by wireless operation with each door open (Courtesy SW ON), the buzzer sounds. If all the doors are closed, doors are unlocked by wireless operation or buzzer keeps sounding for 10 seconds, the buzzer sounding stops.

5. ILLUMINATED ENTRY FUNCTION

If the doors are unlocked when all the doors are locked, the room light is turned on.

6. PANIC MODE FUNCTION

When the lock switch on the transmitter is kept pressed for approximately 2.5 sec., the theft deterrent ECU receives the signal and enters the panic mode. The theft alarm goes on upon receiving the signal, the theft deterrent ECU, and the headlights and taillights flash through the communication of the theft deterrent ECU and door ECU etc. At this time, when any SW on the transmitter is pressed, the panic mode is cancelled, the theft alarm is stopped, and the headlights and taillights go off.

7. REPEAT FUNCTION

If the lock detection signal in response to the output signal is not received after theft deterrent ECU has output the lock signal, the lock signal is output again after approximately 1 sec.

SERVICE HINTS

D25 (B) DRIVER DOOR ECU

- (B) 5-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position
- (B) 4, (B) 6-GROUND : Always approx. **12** volts
- (B) 1-GROUND : Always continuity

F17 (B) FRONT PASSENGER DOOR ECU

- (B) 5-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position
- (B) 4, (B) 6-GROUND : Always approx. **12** volts
- (B) 1-GROUND : Always continuity

R13 REAR DOOR LH ECU

- 26-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position
- 1, 2-GROUND : Always approx. **12** volts
- 6-GROUND : Always continuity

R14 REAR DOOR RH ECU

- 26-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position
- 1, 2-GROUND : Always approx. **12** volts
- 6, 15-GROUND : Always continuity

T5 THEFT DETERRENT ECU

- 24-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position
- 31-GROUND : Approx. **12** volts with ignition SW at **ON** or **ACC** position
- 1, 21-GROUND : Always approx. **12** volts
- 20-GROUND : Always continuity

○ : PARTS LOCATION


Code	See Page	Code	See Page	Code	See Page
D13	50	F23	50	K1	44
D14	50	F24	50	K4	48
D15	50	F25	50	P13	52
D16	50	G3	47	R13	52
D18	50	I19	51	R14	52
D24	50	J10	47	R32	52
D25	50	J11	47	R35	52
D29	50	J12	47	R36	52
D31	50	J13	47	R37	52
D32	50	J14	47	T5	49
D33	50	J15	47	T9	49
D38	50	J21	51	U7	49
F16	50	J27	51		
F17	50	J30	51		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)
DE	29	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
DF		
DI	31	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)
PE	36	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
PG		
PI	37	Floor Wire and Passenger Side J/B (Right Kick Panel)
PJ		

 : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	58	Front Door LH Wire and Floor No.2 Wire (Left Kick Panel)
IC5	58	Instrument Panel Wire and Floor No.2 Wire (Cowl Side Panel LH)
IH4	60	Instrument Panel Wire and Engine Room Main Wire (Cowl Side Panel RH)
II1	60	Instrument Panel Wire and Roof Wire (Cowl Side Panel RH)
II2		
IJ1	60	Front Door RH Wire and Floor Wire (Right Kick Panel)
BA1	62	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BA2		
BB1	62	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BB2		
BC2	62	Floor No.2 Wire and Floor Wire (Rear Floor Partition Panel LH)

 : GROUND POINTS

Code	See Page	Ground Points Location
IH	58	Right Side of Shift Lever
II		
IR	58	Under the Front Passenger's Seat
BL	62	Rear Floor Partition Panel LH
BN	62	Rear Floor Partition Panel RH
BO	62	Quarter Panel RH

 : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I7	60	Instrument Panel Wire			