


POWER TILT AND POWER TELESCOPIC STEERING COLUMN

HOW TO PROCEED WITH TROUBLESHOOTING

DI237-11

Perform troubleshooting in accordance with the procedure on the following page.



CUSTOMER PROBLEM ANALYSIS CHECK

POWER TILT AND POWER TELESCOPIC STEERING SYSTEM CHECK SHEET


Inspector's Name : _____

| | | | |
|-------------------------|-----|-------------------|----------|
| Customer's Name | | Registration No. | |
| | | Registration Year | / / |
| | | Frame No. | |
| Date Vehicle Brought In | / / | Odometer Reading | km miles |

| | |
|-----------------------------|---|
| Date Problem First Occurred | / / |
| Frequency Problem Occurs | <input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day) |

| | | |
|----------|--|---|
| Symptoms | Manual Function does not Operate | <input type="checkbox"/> Both Tilt and Telescopic <input type="checkbox"/> Tilt only <input type="checkbox"/> Telescopic only |
| | Auto Away/Return Function does not Operate | <input type="checkbox"/> Both Auto Away and Auto Return <input type="checkbox"/> Auto Away only <input type="checkbox"/> Auto Return only |

| | | |
|-----------|----------|---|
| DTC Check | 1st Time | <input type="checkbox"/> Normal Code <input type="checkbox"/> Malfunction Code (Code) |
| | 2nd Time | <input type="checkbox"/> Normal Code <input type="checkbox"/> Malfunction Code (Code) |



PRE-CHECK


1. DESCRIPTION

(a) DIAGNOSIS SYSTEM

When troubleshooting multiplex OBD (M-OBD) vehicles, the only difference from the usual troubleshooting procedure is that you connect the LEXUS hand-held tester to vehicle, and read off various data output from the vehicle's power tilt and power telescopic ECU.

The power tilt and power telescopic ECU records the applicable DTCs when the computer detects a malfunction in the computer itself or its circuit.

To check the DTCs, connect a LEXUS hand-held tester to DLC3 on the vehicle. The LEXUS hand-held tester enables you to erase the DTCs and activate the several actuators and check freeze frame data and various forms on steering data.



(b) DATA LINK CONNECTOR 3 (DLC3)


The power tilt and power telescopic ECU uses ISO 14230 for communication. The terminal arrangement of DLC3 complies with SAE J1962 and matches the ISO 14230 format.

| Terminal No. | Connection | Voltage or Resistance | Condition |
|--------------|------------------|---------------------------|---------------------|
| 7 | Bus + Line | Pulse generation | During transmission |
| 4 | Chassis Ground | ↔ Body Ground 1 Ω or less | Always |
| 16 | Battery Positive | ↔ Body Ground 9 – 14 V | Always |

HINT:

If your display shows "UNABLE TO CONNECT TO VEHICLE" when you have connected the cable of LEXUS hand-held tester to DLC3, turned the ignition switch ON and operated the LEXUS hand-held tester, there is a problem on the vehicle side or tester side.

- If communication is normal when the tester is connected to another vehicle, inspect DLC3 on the original vehicle.
- If communication is still not possible when the tester is connected to another vehicle, the problem is probably in the tester itself, so consult the service department listed in the tester's operator's manual.



2. DIAGNOSIS INSPECTION


- (a) Check the DTC.
- (1) Prepare the LEXUS hand-held tester.
 - (2) Connect the LEXUS hand-held tester to DLC3 at the lower of the instrument panel.
 - (3) Turn the ignition switch ON and turn the LEXUS hand-held tester switch ON.
 - (4) Use the LEXUS hand-held tester to check the DTCs and freeze frame data, note or print them (See the operator's manual for operating instructions.).
 - (5) See page [DI-504](#) to confirm the details of the DTC.
- (b) Clear the DTC.
- The following actions will erase the DTC and freeze frame data.
- When using the LEXUS hand-held tester:
Operating the LEXUS hand-held tester to erase the DTCs (See the operator's manual for operating instructions.).
 - When not using the LEXUS hand-held tester:
Disconnecting the battery terminals.

DIAGNOSTIC TROUBLE CODE CHART


If a DTC is displayed during the DTC check, check the circuit for that code listed in the table below. For details of each code, turn to the page referred to under the "See page" for the respective "DTC No." in the DTC chart.

| DTC No. (See Page) | Detection Item | Trouble Area |
|-----------------------|--|---|
| B2602 (DI-508) | Key unlock warning switch malfunction | <ul style="list-style-type: none"> • Key unlock warning switch |
| B2610 (DI-509) | Tilt position sensor or tilt motor malfunction | <ul style="list-style-type: none"> • Sensor power source circuit • Actuator power source circuit • Tilt motor circuit • Power tilt and power telescopic ECU |
| B2611 (DI-511) | Telescopic position sensor or telescopic motor malfunction | <ul style="list-style-type: none"> • Sensor power source circuit • Actuator power source circuit • Telescopic motor circuit • Power tilt and power telescopic ECU |
| B2620 (DI-513) | ECU power source circuit malfunction | <ul style="list-style-type: none"> • Battery • ECU power source circuit • Power tilt and power telescopic ECU |
| B2621 (DI-515) | Communication interruption | <ul style="list-style-type: none"> • Multiplex communication system • Power tilt and power telescopic ECU |

PARTS LOCATION



TERMINALS OF ECU



F05341

| Symbols (Terminals No.) | Wiring Color | Condition | STD Voltage (V) |
|----------------------------|--------------|--|-----------------|
| A2 (P9-1) – COM2 (P9-9) | B – G | IG switch ON, telescopic extended or contracted by manual switch | 190 – 230 (AC) |
| +B (P9-4) – GND (P8-6) | L-W – W-B | Always | 10 – 14 (DC) |
| A1 (P9-7) – COM1 (P9-15) | B – G | IG switch ON, tilt up or down by manual switch | 190 – 230 (AC) |
| B2 (P9-8) – COM2 (P9-9) | W – G | IG switch ON, telescopic extended or contracted by manual switch | 190 – 230 (AC) |
| S5V2 (P9-12) – SG2 (P9-10) | W-R – W-L | IG switch ON | 4.5 – 5.5 (DC) |
| S5V1 (P9-13) – SG1 (P9-14) | B-L – B-O | IG switch ON | 4.5 – 5.5 (DC) |
| B1 (P9-16) – COM1 (P9-15) | W – G | IG switch ON, tilt up or down by manual switch | 190 – 230 (AC) |
| ECUB (P8-1) – GND (P8-6) | R-B – W-B | Always | 10 – 14 (DC) |
| IG (P8-4) – GND (P8-6) | R-L – W-B | IG switch ON | 10 – 14 (DC) |
| | | IG switch LOCK | Below 1 (DC) |

NOTICE:

To distinguish trouble and replace it, take necessary electrical shock prevention operation.

PROBLEM SYMPTOMS TABLE

This system uses the multiplex communication system, so check diagnosis system of the multiplex communication system before you proceed with troubleshooting.


The table below will be useful for you in troubleshooting these electrical systems. The most likely causes of the malfunction are shown in the order of their probability. Inspect each part in the order shown, and replace the part when it is found to be faulty.


If the instruction "Proceed to next circuit inspection shown on the chart" is given in the flow chart for each circuit, proceed to the circuit with the next highest number in the table to continue the check.

If the problem still occurs even though there are no abnormalities in any of the other circuits, then check and replace ECU.

| Symptom | Suspect Area | See page |
|---|--|---|
| Both tilt and telescopic: Manual, auto away/return and memory functions <ul style="list-style-type: none"> Do not operate Stop part way Do not stop | <ol style="list-style-type: none"> ECU power source circuit Key unlock warning switch Actuator power source circuit Sensor power source circuit Tilt motor circuit Telescopic motor circuit Power tilt and power telescopic ECU | <p>DI-517</p> <p>BE-25</p> <p>DI-519</p> <p>DI-522</p> <p>DI-524</p> <p>DI-527</p> <p>IN-34</p> |
| Tilt only: Manual, auto away/return and memory functions <ul style="list-style-type: none"> Do not operate Stop part way Do not stop | <ol style="list-style-type: none"> Sensor power source circuit Tilt motor circuit Power tilt and power telescopic ECU | <p>DI-522</p> <p>DI-524</p> <p>IN-34</p> |
| Telescopic only: Manual, auto away/return and memory functions <ul style="list-style-type: none"> Do not operate Stop part way Do not stop | <ol style="list-style-type: none"> Sensor power source circuit Telescopic motor circuit Power tilt and power telescopic ECU | <p>DI-522</p> <p>DI-527</p> <p>IN-34</p> |
| Both tilt and telescopic: Only tilt and telescopic manual switch function does not operate | <ol style="list-style-type: none"> Tilt and telescopic manual switch circuit Power tilt and power telescopic ECU | <p>DI-1009</p> <p>IN-34</p> |
| Tilt only: Only tilt and telescopic manual switch function does not operate | <ol style="list-style-type: none"> Tilt and telescopic manual switch circuit Power tilt and power telescopic ECU | <p>DI-1009</p> <p>IN-34</p> |
| Telescopic only: Only tilt and telescopic manual switch function does not operate | <ol style="list-style-type: none"> Tilt and telescopic manual switch circuit Power tilt and power telescopic ECU | <p>DI-1009</p> <p>IN-34</p> |
| Both away and return: Only auto away/return function does not operate | <ol style="list-style-type: none"> Check status of auto away function using LEXUS hand-held tester Ignition switch Key unlock warning switch Power tilt and power telescopic ECU | <p>–</p> <p>BE-25</p> <p>BE-25</p> <p>IN-34</p> |
| Only away: Only auto away/return function does not operate | <ol style="list-style-type: none"> Key unlock warning switch Ignition switch Power tilt and power telescopic ECU | <p>BE-25</p> <p>BE-25</p> <p>IN-34</p> |
| Only return: Only auto away/return function does not operate | <ol style="list-style-type: none"> Key unlock warning switch Ignition switch Power tilt and power telescopic ECU | <p>BE-25</p> <p>BE-25</p> <p>IN-34</p> |

POWER TILT AND POWER TELESCOPIC





POWER TILT AND POWER TELESCOPIC

SYSTEM OUTLINE

This system provides the automatic tilt and telescopic mechanisms using the motor drive and ECU control, allowing variable steering movement in the back and forth, and vertical directions. This makes it possible to set the steering to the desired steering position and move the steering to a position where the driver can easily get off the vehicle, allowing easier seating. Additionally, by linking the power seat and remote control mirror, an optimal driving position corresponding to the driver's needs can be stored into the memory.

1. AUTO RETURN OPERATION

When the ignition key is inserted into the key cylinder, the signal is input to the tilt and telescopic ECU through communication control of the J/B ECU and door ECU etc. This activates the ECU to automatically return the steering to the position set before the ignition key has been removed.

2. AUTO AWAY OPERATION

When the ignition key is turned from ON to OFF and removed from the key cylinder, the signal is input to the tilt and telescopic ECU through communication control of the J/B ECU and door ECU etc. This activates the ECU to automatically move the steering to the top tilt step position and maximum telescopic retract position.

3. MANUAL OPERATION

If the TILT and TELESCOPIC SW is operated when the ignition key is inserted in the ignition key cylinder, the signal is sent to the power tilt and power telescopic ECU by the multiplex communication. As a result of that, the power tilt and power telescopic ECU controls the motor to adjust the telescopic position or the tilt position at will.

4. DRIVING POSITION MEMORY FUNCTION

The pulse signals detected by the tilt and telescopic sensors are input to the ECU. This makes it possible to store and recall the desired driving position through communication control of the J/B ECU and door ECU etc.

SERVICE HINTS

P8 (A), P9 (B) POWER TILT AND POWER TELESCOPIC ECU

- (B) 4, (A) 1-GROUND : Always approx. 12 volts
- (A) 4-GROUND : Approx. 12 volts with ignition SW at **ON** or **ST** position
- (A) 6-GROUND : Always continuity

○ : PARTS LOCATION

| Code | See Page | Code | See Page | Code | See Page |
|---------|----------|---------|----------|--------|----------|
| C14 | 46 | J9 | 47 | P9 B | 48 |
| D5 | 47 | J13 | 47 | T4 | 49 |
| D24 A | 50 | J14 A | 47 | T5 | 49 |
| D25 B | 50 | J15 B | 47 | T6 | 49 |
| D26 | 50 | L14 | 51 | T9 | 49 |
| G3 | 47 | P8 A | 48 | U7 | 49 |

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

| Code | See Page | Junction Block and Wire Harness (Connector Location) |
|------|----------|---|
| DE | 29 | Instrument Panel Wire and Driver Side J/B (Left Kick Panel) |
| DF | | |
| DG | | |
| DI | 31 | Floor No.2 Wire and Driver Side J/B (Left Kick Panel) |
| PE | 36 | Instrument Panel Wire and Passenger Side J/B (Right Kick Panel) |

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location) |
|------|----------|--|
| IA1 | 58 | Front Door LH Wire and Floor No.2 Wire (Left Kick Panel) |
| IC3 | 58 | Instrument Panel Wire and Floor No.2 Wire (Cowl Side Panel LH) |

▽ : GROUND POINTS

| Code | See Page | Ground Points Location |
|------|----------|-------------------------------|
| IG | 58 | Left Side of Instrument Panel |
| IH | 58 | Right Side of Shift Lever |