


INSPECTION

1. REMOVE MASS AIR FLOW (MAF) METER

- (a) Disconnect the mass air flow (MAF) meter connector.
- (b) Remove the 2 screws, mass air flow (MAF) meter and O-ring.




2. INSPECT MASS AIR FLOW (MAF) METER RESISTANCE

Using an ohmmeter, measure the resistance between terminals THA and E2.

Resistance:

Terminals	Resistance	Temperature
THA - E2	13.6 - 18.4 k Ω	-20°C (-4°F)
THA - E2	2.21 - 2.69 k Ω	20°C (68°F)
THA - E2	0.49 - 0.67 k Ω	60°C (140°F)

If the resistance is not as specified, replace the mass air flow (MAF) meter.



3. INSPECT MASS AIR FLOW (MAF) METER OPERATION

- (a) Connect the mass air flow (MAF) meter connector.
- (b) Turn the ignition switch ON.
- (c) Using a voltmeter, connect the positive (+) tester probe to terminal VG, and negative (-) tester probe to terminal E2G.
- (d) Blow air into the mass air flow (MAF) meter, and check that the voltage fluctuates.

If operation is not as specified, replace the mass air flow (MAF) meter.

- (e) Turn the ignition switch LOCK.
- (f) Disconnect the mass air flow (MAF) meter connector.

4. INSTALL MASS AIR FLOW (MAF) METER

- (a) Install a new O-ring and the mass air flow (MAF) meter with the 2 screws.
- (b) Connect the mass air flow (MAF) meter connector.