


DTC	B1428	REAR SOLAR SENSOR CIRCUIT
------------	--------------	----------------------------------


CIRCUIT DESCRIPTION



A photodiode in the A/C solar sensor detects solar radiation and sends signals to the A/C amplifier.

DTC No.	Detection Item	Trouble Area
B1428	Rear solar sensor circuit (Rear side) (Open or short)	<ul style="list-style-type: none"> • A/C solar sensor (Rear solar sensor) • Harness or connector between A/C solar sensor (Rear solar sensor) and A/C amplifier • A/C amplifier

WIRING DIAGRAM



C

I36284

INSPECTION PROCEDURE

1	READ VALUE ON HAND-HELD TESTER
----------	---------------------------------------

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch to the ON position and push the hand-held tester main switch on.
- (c) Select the item below in the DATA LIST, and read the display on the hand-held tester.

DATA LIST / AIR CONDITIONER:

Item	Measure Item/Display (Range)	Normal Condition	Diagnostic Note
REAR SOLAR SENS	Rear solar sensor / min.: 0 max.: 255	Changes depending on brightness	-

OK:

The display is as specified in the normal condition.

Result:


NG	A
OK (Checking from the PROBLEM SYMPTOM TABLE)	B
OK (Checking from the DTC)	C

B	PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-885)
----------	---

C	REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)
----------	--

A

2 INSPECT AIR CONDITIONING AMPLIFIER(TSRr - GND)



- (a) Remove the A/C amplifier with connector still connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A11-30 (TSRr) - A12-16 (S5-4)	Sensor is subjected to electric light	0.8 to 4.3 V
A11-30 (TSRr) - A12-16 (S5-4)	Sensor is covered by a cloth	Below 0.8 V

HINT:

- As the temperature increases, the voltage decreases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the solar sensor.

Result:


NG	A
OK (Checking from the PROBLEM SYMPTOMS TABLE)	B
OK (Checking from the DTC)	C

B → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-885)**

C → **REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)**

A

3 INSPECT A/C SOLAR SENSOR



- (a) Remove the A/C solar sensor.
- (b) Measure the resistance according to the value(s) in the table below.
- (c) Connect the positive (+) lead from the ohmmeter to terminal 1 and negative (-) lead to terminal 2 of the A/C solar sensor.

Standard:

Tester connection	Condition	Specified condition
A29-1 - A29-2	Sensor is subjected to electric light	Except $\infty \Omega$
A29-1 - A29-2	Sensor is covered by a cloth	$\infty \Omega$ (No continuity)

NOTICE:

The connection procedure for using a digital tester such as a TOYOTA electrical tester is shown above. When using an analog tester, connect the positive (+) lead to terminal 2 and negative (-) lead to terminal 1 of the solar sensor.

HINT:


- As the inspection light is moved away from the sensor, the voltage increases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the solar sensor.

NG **REPLACE A/C SOLAR SENSOR**


OK

4 CHECK HARNESS AND CONNECTOR(A/C SOLAR SENSOR - AIR CONDITONING AMPLIFIER)

**A/C Solar Sensor Connector
Front View:**



**Air Conditioning Amplifier Connector
Wire Harness View:**



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A11-30 (TSRr) - A29-2	Always	Below 1 Ω
A12-16 (S5-4) - A29-1	Always	Below 1 Ω
A11-30 (TSRr) - Body ground	Always	10 kΩ or higher
A12-16 (S5-4) - Body ground	Always	10 kΩ or higher

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)