


# ENGINE (1MZ-FE/3MZ-FE)

141DH-01

## INSPECTION

1. INSPECT COOLANT (See page 16-1)
2. INSPECT ENGINE OIL
3. INSPECT BATTERY  
Standard specific gravity: 1.25 to 1.29 at 20°C (68°F)
4. INSPECT AIR CLEANER FILTER ELEMENT SUB-ASSY
5. INSPECT SPARK PLUG (See page 18-3)



### 6. INSPECT V-RIBBED BELT

- (a) Belt deflection:  
Pressing force: 98 N (10 kgf, 22 lbf)

	New belt mm (in.)	Used belt mm (in.)
V ribbed belt (For fan and generator)	9.1 to 10.5 (0.358 to 0.413)	11.0 to 13.5 (0.433 to 0.531)
V ribbed belt (for vane pump)	7 to 9 (0.276 to 0.354)	10 to 12 (0.394 to 0.472)

- (b) Tension:

	New belt N (kg, lb)	Used belt N (kg, lb)
V ribbed belt (for fan and generator)	617 to 853 (63 to 87, 139 to 192)	294 to 490 (30 to 50, 66 to 110)
V ribbed belt (for vane pump)	686 to 784 (70 to 80, 154 to 176)	343 to 490 (35 to 50, 77 to 110)

### NOTICE:


- Check the drive belt deflection at the specified point.
- When installing a new belt, set its tension value as specified.
- When inspecting a belt which is used for over 5 minutes, apply the specification of "Used belt".
- When reinstalling a belt which is used for over 5 minutes, adjust its belt deflection and tension to the medium value in each specification of "Used belt".
- V-ribbed belt tension and deflection value should be checked after 2 revolutions of engine cranking.
- When using a belt tension gauge, confirm the accuracy first by using a master gauge.

### 7. INSPECT IGNITION TIMING

- (a) Warm up engine.
- (b) When using hand-held tester.
- (1) Connect the hand-held tester to the DLC3.
  - (2) Enter DATA LIST MODE on the hand-held tester.
- Ignition timing : 8 to 12° BTDC**

### HINT:

Please refer to the hand-held tester operator's manual if you need help to select DATA LIST.




- (c) When not using hand-held tester:
- (1) Using SST, connect terminals 13 (TC) and 4 (CG) of DLC3.

SST 09843-18040

**NOTICE:**

- **Make sure of the terminal numbers before connecting them. Connection with a wrong terminal can damage the engine.**
- **Turn OFF all electrical systems before connecting the terminals.**
- **Perform this inspection after the cooling fan motor is turned OFF.**

- (2) Remove the V-bank cover.



- (3) Pull out the black-colored wire harness as shown in the illustration.

- (4) Connect the tester terminal of the timing light to the engine.

**NOTICE:**

**Use a timing light which detects the first signal.**

- (5) Inspect ignition timing at idle.

**Ignition timing : 8 to 12° BTDC**

**NOTICE:**

**When checking the ignition timing, the transmission is in neutral position.**

**HINT:**

Run the engine at 1,000 to 1,300 rpm for 5 seconds, check that the engine rpm returns idle speed.

- (6) Disconnect terminals 13 (TC) and 4 (CG) of the DLC3.

- (7) Inspect ignition timing at idle.

**Ignition timing : 7 to 24° BTDC**

- (8) Confirm that the ignition timing advances when the engine rpm is increased.

- (9) Remove the timing light.

**8. INSPECT ENGINE IDLE SPEED**

- (a) Warm up the engine.

- (b) When using hand-held tester:

- (1) Connect the hand-held tester to the DLC3.

- (2) Enter DATA LIST MODE on the hand-held tester.


**Idle speed: 650 to 750 rpm.**

**NOTICE:**

- **When checking the idle speed, the transmission is in the neutral position.**
- **Check the idle speed with the cooling fan OFF.**
- **Switch off all accessories and air conditioning before connecting the hand-held tester.**

**HINT:**

Please refer to the hand-held tester operator's manual for further details.



- (c) When not using hand-held tester:
- (1) Using SST, connect the tachometer test probe to terminal 9 (TAC) of DLC3.  
SST 09843-18040
  - (2) Check the idle speed.  
**Idle speed: 650 to 750 rpm.**

**NOTICE:**

- **When checking the idle speed, the transmission is in the neutral position.**
- **Check the idle speed with the cooling fan OFF.**
- **Switch off all accessories and air conditioning before connecting the hand-held tester.**

**9. INSPECT COMPRESSION**

- (a) Warm up and stop the engine.
  - (b) Disconnect the injector connectors.
  - (c) Remove the intake air surge tank. (See page 14-7)
  - (d) Remove the ignition coil.
  - (e) Remove the spark plugs.
- (f) Inspect cylinder compression pressure.  
SST 09992-00500
- (1) Insert a compression gauge into the spark plug hole.
  - (2) Fully open the throttle.
  - (3) While cranking the engine, measure the compression pressure.

**Compression pressure:**

**1.5 MPa (15.3 kgf/cm<sup>2</sup>, 218 psi)**

**Minimum pressure:**


**1.0 MPa (10.2 kgf/cm<sup>2</sup>, 145 psi)**

**Difference between each cylinder:**

**100 kPa (1.0 kgf/cm<sup>2</sup>, 15 psi)**

**NOTICE:**

- **Always use a fully charged battery to obtain engine speed of 250 rpm or more.**
  - **Check other cylinder's compression pressure in the same way.**
  - **This measurement must be done in as short a time as possible.**
- (4) If the cylinder compression is low, pour a small amount of engine oil into the cylinder through the spark plug hole and inspect again.



HINT:

- If adding oil increases the compression, the piston rings and/or cylinder bore may be worn or damaged.
- If pressure stays low, a valve may be sticking or seating improperly, or there may be leakage past the gasket.

**10. INSPECT CO/HC**

- (a) Start the engine.
- (b) Run the engine at 2,500 rpm for approximately 180 seconds.
- (c) Insert CO/HC meter testing probe at least 40 cm (1.3 ft) into tailpipe during idling.
- (d) Check CO/HC concentration .

If the CO/HC concentration does not conform to specifications, perform trouble shooting in the order given below.

- (1) Check heated oxygen sensor operation. ([See page 12-5](#))
- (2) See the table below for possible causes, and then inspect and repair the applicable causes if necessary.

CO	HC	Problems	Causes
Normal	High	Rough idle	1. Faulty ignitions: <ul style="list-style-type: none"> <li>• Incorrect timing</li> <li>• Fouled, shorted or improperly gapped plugs</li> </ul> 2. Incorrect valve clearance 3. Leaks in intake and exhaust valves 4. Leaks in cylinders
Low	High	Rough idle (Fluctuating HC reading)	1. Vacuum leaks: <ul style="list-style-type: none"> <li>• PCV hoses</li> <li>• Intake manifold</li> <li>• Throttle body</li> <li>• Brake booster line</li> </ul> 2. Lean mixture causing misfire
High	High	Rough idle (Black smoke from exhaust)	1. Restricted air filter 2. Plugged PCV valve 3. Faulty EFI systems: <ul style="list-style-type: none"> <li>• Faulty pressure regulator</li> <li>• Defective engine coolant temperature sensor</li> <li>• Defective mass air-flow meter</li> <li>• Faulty ECM</li> <li>• Faulty injectors</li> <li>• Faulty throttle position sensor</li> </ul>