

Technical Service Information Bulletin November 10, 2004



'02 - '05 SC 430

**Introduction** The navigation system door can now be replaced without having to replace the complete instrument cluster with multi–display unit. Use the following procedures to replace the navigation system door.

Applicable • 2002 – 2005 model year SC 430 vehicles equipped with Lexus Navigation System.
 Vehicles

| Parts<br>Information | PREVIOUS<br>PART NUMBER | CURRENT<br>PART NUMBER | INTERIOR<br>COLOR | PARTNAME                                 | QTY |
|----------------------|-------------------------|------------------------|-------------------|--|-----|
|                      | N/A                     | 55412-24050-B0         | Ecru Brown        | Panel, Instrument<br>Cluster Finish, CTR | 1   |
|                      |                         | 55412-24050-D0         | Red               |  |     |
|                      |                         | 55412-24050-E0         | Saddle/Black      |  |     |

| Warranty<br>Information | OP CODE | DESCRIPTION           | TIME | OFP            | T1 | T2 |
|-------------------------|---------|-----------------------|------|----------------|----|----|
|                         | BD4016  | R & R Navigation Door | 0.4  | 55401–24100–C0 | 99 | 99 |

### Applicable Warranty\*:

This repair is covered under the Lexus Comprehensive Warranty. This warranty is in effect for 48 months or 50,000 miles, whichever occurs first, from the vehicle's in-service date.

\* Warranty application is limited to correction of a problem based upon a customer's specific complaint.

Precaution

### NOTE:


- Refer to the Technical Information System (TIS), applicable model year SC 430 Repair Manual for the procedure for removing the instrument cluster finish panel sub-assembly center with multi-display.
- Be careful not to install improper types of screws.




BODY


BO011

- Preparation Procedure
  - n 1. Remove Air Conditioner Control Assembly.
    e 2. Remove Instrument Panel Safety Pad Garnish Sub–assembly.
    - \_\_\_\_\_\_
    - 3. Remove Instrument Panel Garnish Sub-assembly No. 2.
    - 4. Remove Instrument Cluster Finish Panel Sub–assembly Center.
      - A. Remove the 2 bolts and 2 screws.
      - B. Disconnect the connector, then remove the multi–display (Center Display) display and instrument cluster finish panel sub–assembly center and clip.






- Repair Procedure
- 1. Remove Instrument Panel Upper Bracket No. 2 (2005 model year only).
  - A. Remove the 4 screws from the instrument panel upper bracket No. 2.
  - B. Remove the instrument panel upper bracket No. 2.
- 2. Remove Instrument Panel Finish Panel Upper.
  - A. Remove the 4 screws from the instrument panel finish panel upper.
  - B. Remove the instrument panel finish panel upper.



- Loosen Instrument Panel Finish Panel No. 1 Retainer.
  - A. Loosen the 5 screws which secure the instrument panel finish panel No. 1 retainer.

## NOTE:

Do not loosen ground screw.



Procedure (Continued)

Repair

- 4. Remove Instrument Cluster Finish Panel Center Sub–assembly.
  - A. Pull the shaft of the instrument cluster finish lower panel sub–assembly backward to fully open the instrument cluster finish panel center.
  - B. Separate the 2 clamps, and then carefully remove the instrument cluster finish panel center sub–assembly.

### NOTE:

Increase the width of the instrument panel finish panel No. 1 and No. 2 retainers by pushing them outward by approximately 2 mm (0.079 in.), and them remove the instrument cluster finish panel center sub–assembly.


- 5. Replace Instrument Cluster Finish Panel Center.
  - A. Remove the 3 screws, and then remove the instrument cluster finish panel center.
  - B. Install a new instrument cluster finish panel center on the instrument cluster finish lower panel sub–assembly.




Be careful not to damage the 3 positioning claws in area A.

C. Tighten the 3 screws.


Torque: 0.67 to 0.71 N•m (6.83 to 7.24 kgf•cm, 0.49 to 0.52 ft•lbf)





# Repair 6. Procedure

- (Continued)
- 6. Install Instrument Cluster Finish Panel Center Sub–assembly.
  - A. Install the instrument cluster finish panel center sub–assembly.
  - B. Fit the shaft of the instrument cluster finish lower panel sub–assembly into the 2 clamps.
  - C. Pull the shaft of the instrument cluster finish lower panel sub-assembly backward.





## NOTE:

Increase the width of the instrument panel finish panel No. 1 and No. 2 retainers by pushing them outward by approximately 2 mm (0.079 in.), and then fit the rollers into the rail grooves.

 D. Tighten the 5 screws on the instrument panel finish panel
 No. 1 retainer with the specified amount of torque.

Torque: 0.67 to 0.71 N•m (6.83 to 7.24 kgf•cm, 0.49 to 0.52 ft•lbf)





## HINT:

Fit the rollers into the rail grooves as shown in the illustration.

- **Repair** 7. Install Instrument Panel Finish **Procedure** Panel Upper.
- (Continued)
- Panel Upper.
  - A. Install the instrument panel finish panel upper.
  - B. Tighten the 4 screws.

Torque: 0.67 to 0.71 N•m (6.83 to 7.24 kgf•cm, 0.49 to 0.52 ft•lbf)

C. Check to make sure the instrument finish panel center sub–assembly slides smoothly by moving the motor assembly forward and rearward.

## NOTE:

Motor assembly must be moved to the end of its travel prior to reassembly in vehicle (panel open position).

- Install Instrument Panel Upper Bracket No. 2 (2005 model year only).
  - A. Install the instrument panel upper bracket No. 2.
  - B. Tighten the 4 screws.

Torque: 0.67 to 0.71 N•m (6.83 to 7.24 kgf•cm, 0.49 to 0.52 ft•lbf)

- 9. Check Operation.
  - A. After assembling the instrument cluster finish panel sub–assembly center with multi–display, visually check the appearance to make sure that the instrument cluster finish panel center is centered.
  - B. Check that instrument cluster finish panel center operates properly.
- 10. Reinstallation is the Reverse Order of Removal.
- 11. Function Test Operation of the Navigation Unit.

