


### Indicator Indication of ATF Temperature

Below Proper Temperature	Proper Temperature	Higher than Proper Temperature
Data list: A/T OIL TEMP1 36°C (97°F) or less	Data list: A/T OIL TEMP1 36 to 46°C (97 to 115°F)	Data list: A/T OIL TEMP1 46°C (115°F) or higher
A/T OIL TEMP light Turns off	A/T OIL TEMP light Turns on	A/T OIL TEMP light Blinking

#### NOTICE:

Perform the fluid level inspection while the indicator light is on.



### 6. FLUID LEVEL CHECK

#### NOTICE:

The fluid temperature must be between 36°C (97°F) and 46°C (115°F) to accurately check the fluid level.

- Remove the overflow plug with the engine idling.
- Check that the fluid comes out of the overflow tube.

If fluid does not come out, proceed to step 7.

If fluid comes out, wait until the overflow slows to a trickle and proceed to step 8.

### 7. TRANSMISSION REFILL

- Install the overflow plug.
- Stop the engine.
- Remove the refill plug.
- Add 0.4 liters (0.42 US qts, 0.35 Imp qts) of fluid.
- Allow the engine to idle and wait for 10 seconds.
- Proceed to step 6.

### 8. COMPLETE

- Install the overflow plug with a new gasket.  
**Torque: 20 N·m (205 kgf·cm, 15 ft·lbf)**
- Stop the engine.
- Install the refill plug with a new gasket.  
**Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)**