



- (m) Pull down the driver side under dash trim panel to expose the foot light connector and disengage it (Fig. 1-10).
- (n) Place masking tape along the bottom edge of the passenger side knee panel.




- (o) Use a nylon removal tool to release the 4 clips on the under dash trim panel (Fig. 1-11).




- (p) Lower the panel to expose the foot light connector. Disconnect it and remove the panel (Fig. 1-12).
- (q) Remove the masking tape and ensure no tape residue remains.

2. Install the Driver Side Door Sill.


- (a) Locate the 67 pin connector on the driver side kick panel connector block (Fig. 2-1).




- (b) Push the locking tab up and pull the black lock mechanism out to remove the connector from the connector block (Fig. 2-2).




- (c) Remove the black lock mechanism (Fig. 2-3).





(d) Locate the violet wire (CTY[-], pin 1) (Fig. 2-4).




(e) Connect the violet wire from the door sill to the violet wire on the vehicle connector with a Scotchlok (Fig. 2-5).

NOTE: Refer to Fig. 2-6 for instructions on proper Scotchlok installation.

(f) Use pliers to push down the metal tab to splice the wires. Make sure both wires are spliced correctly (Fig. 2-6).


(g) Snap the plastic cover in place by hand.


(h) Apply foam tape over the wire tap.




(i) Reattach the black lock mechanism and reconnect it to the connector block (Fig. 2-7).

CAUTION: Make sure the connector lock engages securely.






- (j) Locate the blue wire (B[+], pin 1) on the driver side foot lamp connector (Fig. 2-8).
- (k) Connect the blue wire from the door sill to the foot lamp with a Scotchlok (Fig. 2-8).



- (l) Apply foam tape over the fuse holder and Scotchlock (Fig. 2-9).



- (m) Apply two wire ties (Fig. 2-10).

CAUTION: Make sure the wire is routed above the hood latch cable. Do not attach the wire to the hood latch cable.