

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

### 1. Remove Front Sway Bar.

- Disconnect negative terminal of vehicle battery.
- Remove engine under cover. (Fig 1-1)
- Disconnect steering rack wire harness (E). (Fig 1-2)
- Detach clips holding steering rack W/H to sub-frame.
  - Use a pick or small screwdriver to unlock clips.
- Disconnect bracket (F) from sub-frame. (Fig 1-2)
- Disconnect sway bar link from sway bar. (Fig 1-3)
  - If the ball joint turns together with the nut, use a hexagon (6 mm) wrench to hold the stud.

