



(g) Remove sway bar brackets. (Fig 1-4)

(h) Place tall adjustable stand under sub-frame. ★

(i) Loosen bolts B and C just enough to remove tension from these parts. (Fig 1-5)

(j) Loosen nuts A to the end of the threads on the stud. This should be about 1/2 inch off of the sub-frame. (Fig 1-5)

(k) Lower the front of the sub-frame with the tall adjustable stand.

CAUTION: Do not lower sub frame any further than the threaded portion of the stud. Keep a minimum of 4 threads engaged.

(l) Remove front sway bar. (Fig 1-6)

(1) Shift bar to the driver's side of the vehicle until the passenger side of the sway bar is free from the vehicle sheet metal.

(2) Pull passenger side of sway bar forward and down past the power steering wire-harness and free from the vehicle.

2. Install F-Sport Front Sway Bar.

(a) Slide sway bar into sub frame.

(1) Start by guiding drivers side of bar between sub frame and body as far as possible to the driver's side wheel.

(2) Raise passenger side of bar up and back in between the sub frame and the body of the vehicle.