
Last Modified: 7-13-2007		1.6 A	
Service Category: Engine/Hybrid System	Section: Emission	Section: Emission Control	
Model Year: 2008	Model: ES350	Doc ID: RM00000100L00EX	
Title: 2GR-FE EMISSION CONTROL: AIR FUEL RATIO SENSOR: REMOVAL (2008 ES350)			

REMOVAL

1. REMOVE AIR FUEL RATIO SENSOR



(a) Disconnect the 2 air fuel ratio sensor connectors.

(b) Using SST, remove the 2 air fuel ratio sensors from the front pipe assembly.

SST: 09224-00010



