

| | | |
|--|---------------------|--|
| Last Modified: 7-13-2007 | | 1.6 D |
| Service Category: Audio/Visual/Telematics | | Section: Park Assist/Monitoring |
| Model Year: 2008 | Model: ES350 | Doc ID: RM000000WI100SX |
| Title: PARK ASSIST / MONITORING: INTUITIVE PARKING ASSIST SYSTEM: CUSTOMIZE PARAMETERS (2008 ES350) | | |

CUSTOMIZE PARAMETERS

1. CUSTOMIZE PARAMETERS (TECHSTREAM)

(a) The following items can be customized:

NOTICE:

- When the customer requests a change in a function, first make sure that the function can be customized.
- Be sure to make a note of the current settings before customizing.
- When troubleshooting a function, first make sure that the function is set to the default setting.

Warning

| DISPLAY | DEFAULT | CONTENTS | SETTING |
|-----------------------|---------|--|----------------------|
| Rr Sensor Onset Range | Wide | Function to set buzzer activation range (for rear center sensors) | Narrow / Wide |
| Keep Sense Buzzer | Avail | Function to make buzzer sound when distance between vehicle and obstacle does not change for more than 3 seconds | Not Avail / Avail |
| Fr & Rr Buzzer Volume | M3 | Function to change volume of buzzer | L / M1 / M2 / M3 / H |

Sensor:

| DISPLAY | DEFAULT | CONTENTS | SETTING |
|--------------------|---------|---|-------------------|
| Sensor Condition N | Avail | Function to make sensors available when shift position is N | Not Avail / Avail |

Display:

| DISPLAY | DEFAULT | CONTENTS | SETTING |
|--------------|---------|---------------------------------|--------------|
| Display Mode | All | Function to change display mode | All / Undisp |

