

| | | |
|---|--|-------------------------|
| Last Modified: 7-13-2007 | | 1.6 A |
| Service Category: Audio/Visual/Telematics | Section: Navigation/Multi Info Display | |
| Model Year: 2008 | Model: ES350 | Doc ID: RM0000010GD000X |
| Title: NAVIGATION: NAVIGATION ANTENNA: REMOVAL (2008 ES350) | | |

REMOVAL

1. PRECAUTION

INFO

2. TURN FRONT WHEELS TO FACE STRAIGHT AHEAD

3. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

CAUTION:

Wait for 90 seconds after disconnecting the cable to prevent airbag deployment

INFO

4. REMOVE LOWER NO. 3 STEERING WHEEL COVER

INFO

5. REMOVE LOWER NO. 2 STEERING WHEEL COVER

INFO

6. REMOVE STEERING PAD

INFO

7. REMOVE STEERING WHEEL ASSEMBLY

INFO

8. REMOVE FRONT DOOR SCUFF PLATE LH

INFO

9. REMOVE FRONT DOOR OPENING TRIM COVER LH

INFO

10. REMOVE SIDE INSTRUMENT PANEL LH

INFO

11. REMOVE INSTRUMENT PANEL FINISH PANEL END LH

INFO

12. REMOVE LOWER INSTRUMENT PANEL SUB-ASSEMBLY

INFO

13. REMOVE STEERING COLUMN COVER

INFO

14. REMOVE TURN SIGNAL SWITCH ASSEMBLY WITH SPIRAL CABLE SUB-ASSEMBLY

INFO

15. REMOVE TILT AND TELESCOPIC SWITCH

INFO

16. REMOVE INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY

INFO

17. REMOVE COMBINATION METER ASSEMBLY

INFO

18. REMOVE NO. 1 SWITCH HOLE BASE

INFO

19. REMOVE INSTRUMENT PANEL FINISH PANEL END RH

INFO

20. REMOVE FRONT DOOR SCUFF PLATE RH

INFO

21. REMOVE FRONT DOOR OPENING TRIM COVER RH [INFO](#)
22. REMOVE NO. 2 INSTRUMENT PANEL UNDER COVER SUB-ASSEMBLY [INFO](#)
23. REMOVE SIDE INSTRUMENT PANEL RH [INFO](#)
24. REMOVE FRONT PASSENGER SIDE KNEE AIRBAG ASSEMBLY [INFO](#)
25. REMOVE LOWER INSTRUMENT PANEL RH [INFO](#)
26. REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY [INFO](#)
27. REMOVE UPPER CONSOLE PANEL ASSEMBLY WITH FRONT ASH RECEPTACLE [INFO](#)
28. REMOVE NO. 2 INSTRUMENT PANEL REGISTER ASSEMBLY [INFO](#)
29. REMOVE MULTI-DISPLAY WITH RADIO RECEIVER ASSEMBLY [INFO](#)
30. REMOVE HEATER SEAT SWITCH CONSOLE BASE (w/o Seat Heater System) [INFO](#)
31. REMOVE HEATER SEAT SWITCH CONSOLE BASE (w/ Seat Heater System) [INFO](#)
32. REMOVE CONSOLE BOX POCKET [INFO](#)
33. REMOVE CONSOLE BOX CARPET [INFO](#)
34. REMOVE CONSOLE REAR END PANEL SUB-ASSEMBLY [INFO](#)
35. REMOVE REAR CONSOLE BOX ASSEMBLY [INFO](#)
36. REMOVE FRONT PILLAR GARNISH LH [INFO](#)
37. REMOVE NO. 1 INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY [INFO](#)
38. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY (for LH Side) [INFO](#)
39. REMOVE NO. 1 INSTRUMENT PANEL REGISTER ASSEMBLY [INFO](#)
40. REMOVE FRONT PILLAR GARNISH RH [INFO](#)
41. REMOVE NO. 2 INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY [INFO](#)
42. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY (for RH Side) [INFO](#)
43. REMOVE NO. 3 INSTRUMENT PANEL REGISTER ASSEMBLY [INFO](#)
44. REMOVE NO. 1 SPEAKER HOLE COVER [INFO](#)
45. REMOVE FRONT STEREO COMPONENT SPEAKER ASSEMBLY [INFO](#)
46. REMOVE NO. 1 INSTRUMENT PANEL MOUNTING BRACKET [INFO](#)

47. REMOVE PUSH START SWITCH [INFO](#)

48. DISCONNECT INSTRUMENT PANEL WIRE ASSEMBLY [INFO](#)

49. REMOVE ROOM TEMPERATURE SENSOR [INFO](#)

50. REMOVE INSTRUMENT PANEL SAFETY PAD ASSEMBLY (w/o DVD Player) [INFO](#)

51. REMOVE INSTRUMENT PANEL SAFETY PAD ASSEMBLY (w/ DVD Player) [INFO](#)

52. REMOVE SIDE NO. 1 DEFROSTER NOZZLE DUCT [INFO](#)

53. REMOVE SIDE NO. 2 DEFROSTER NOZZLE DUCT [INFO](#)

54. REMOVE DEFROSTER NOZZLE ASSEMBLY [INFO](#)

55. REMOVE NO. 1 HEATER TO REGISTER DUCT [INFO](#)

56. REMOVE NO. 2 HEATER TO REGISTER DUCT [INFO](#)

57. REMOVE NAVIGATION ANTENNA ASSEMBLY



(a) Disengage the 2 clamps.

(b) Remove the 2 screws and navigation antenna assembly.

