Disengage the Clips at these positions, and also the circles ones

Remove this s First used a s Flat drives tapes edges.