



H

*1	OUTER MIRROR LH	*2	BLIND SPOT MONITOR SENSOR RH (SLAVE)
*3	OUTER REAR VIEW MIRROR INDICATOR LH	*4	OUTER REAR VIEW MIRROR INDICATOR RH
*5	BLIND SPOT MONITOR SENSOR LH (MASTER)	*6	OUTER MIRROR RH
*7	REAR CROSS TRAFFIC ALERT BUZZER (BLIND SPOT MONITOR BUZZER)	-	-