


Wiring Diagram


Combination Meter/Meters, Gauges and Illumination



- *1 • ABS and TRAC ECU
- Engine and ECT ECU
- Suspension ECU
- Cruise Control ECU
- *2 Except. Indicator Needle

Wiring Diagram (Cont'd)


Combination Meter/Warning Lights and Indicator Lights/USA



*1 HEIGHT HI *3 HEIGHT NORM *5 Odometer Illumination
 *2 HEIGHT LO *4 HEIGHT Illumination *6 Alternator L terminal

Wiring Diagram (Cont'd)

Combination Meter/Warning Lights and Indicator Light/CANADA



*1 HEIGHT HI *3 HEIGHT NORM *5 Odometer Illumination
 *2 HEIGHT LO *4 HEIGHT Illumination *6 Alternator L terminal

Wiring Diagram (Cont'd)

Meter Cluster/Warning Lights and Twin Trip Switch

