


























**PREPARATION**

**SST (Special Service Tools)**


	09309-37010	Transmission Bearing Replacer	AUTOMATIC ASSY(A761E)	TRANSMISSION
	09320-89010	Transfer Clutch Spring Compressor	CLUTCH DRUM & INPUT SHAFT ASSY(A761E)	
	09350-30020	TOYOTA Automatic Transmission Tool Set	AUTOMATIC ASSY(A761E) OIL PUMP ASSY(A761E) CLUTCH DRUM & INPUT SHAFT ASSY(A761E)	TRANSMISSION
	(09350-06120)	No.2 Measure Terminal	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09350-07040)	No.2 Piston Spring Compressor	CLUTCH DRUM & INPUT SHAFT ASSY(A761E)	
	(09350-07050)	No.3 Piston Spring Compressor	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09350-07060)	No.1 Snap Ring Expander	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09350-07070)	No.2 Snap Ring Expander	AUTOMATIC ASSY(A761E) CLUTCH DRUM & INPUT SHAFT ASSY(A761E)	TRANSMISSION
	(09350-07080)	Brake Reaction Sleeve Puller	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09350-07090)	Brake No.1 Piston Puller	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09350-07110)	Oil Seal Replacer	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09351-32140)	Oil Seal Replacer	OIL PUMP ASSY(A761E)	
	09351-40010	Tool Set, TOYOTA Automatic Transmission	AUTOMATIC ASSY(A761E)	TRANSMISSION

A761E A/T REPAIR MANUAL (RM1050U)

	(09351-04010)	Pipe	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09351-04020)	Spring Compressor No.1	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09351-04030)	Spring Compressor No.2	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09351-04040)	Plate	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09351-04050)	Bolt	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09351-04060)	Spring Compressor No.3	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09351-04070)	Bolt Set	AUTOMATIC ASSY(A761E)	TRANSMISSION
	09387-00070	First & Reverse Brake Wrench	CLUTCH DRUM & INPUT SHAFT ASSY(A761E)	
	09950-60010	Replacer Set	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09951-00350)	Replacer 85	AUTOMATIC ASSY(A761E)	TRANSMISSION
	09950-70010	Handle Set	AUTOMATIC ASSY(A761E)	TRANSMISSION
	(09951-07100)	Handle 100	AUTOMATIC ASSY(A761E)	TRANSMISSION

A761E A/T REPAIR MANUAL (RM1050U)

**Recommended Tools**

	09031-00030	Pin Punch	AUTOMATIC ASSY(A761E)	TRANSMISSION
---	-------------	-----------	-----------------------	--------------

**SSM**

	08826-00090	"Seal Packing 1281," THREE BOND 1281 or equivalent (FIPG)	AUTOMATIC ASSY(A761E)	TRANSMISSION
--	-------------	---	-----------------------	--------------

**Equipment**

Feeler gauge	
Cylinder Gauge	
Vernier calipers	
Dial indicator	
Micrometer	
Feeler gauge	
Straight edge	
Torque wrench	
Angle gauge	
V block	

**Lubricant**

Automatic transmission fluid		
Dry fill	8.5 liters (9.0 US qts, 7.5 Imp. qts)	ATF TYPE WS or equivalent
Drain and refill	2.3 liters (2.4 US qts, 2.0 Imp. qts)	

**SSM (Special Service Materials)**

	08826-00090	"Seal Packing 1281," THREE BOND 1281 or equivalent (FIPG)	AUTOMATIC ASSY(A750E/A750F)	TRANSMISSION
--	-------------	---	-----------------------------	--------------

A761E A/T REPAIR MANUAL (RM1050U)