Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

ltem	Function	Default setting	Customized setting
Smart access system with push-button start $(\rightarrow P. 5)$	Smart access system with push-button start	ON	OFF
	Operation signal (Emergency flashers)	ON	OFF
	Operation signal (Buzzer)	ON	OFF
Wireless remote con- trol (→P. 19)	Wireless remote con- trol	ON	OFF
	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Automatic door lock function to be activated if door is not opened after being unlocked	ON	OFF

6

6-2. Customization

ltem	Function	Default setting	Customized setting
	Time elapsed before automatic lock function is activated if door is not opened after being unlocked	60 seconds	30 seconds
		00 3000103	120 seconds
Wireless remote con-	Operational signal (Emergency flashers)	ON	OFF
trol (→P. 19)	Operational signal (Buzzer)	ON	OFF
	Door lock buzzer	ON	OFF
	Trunk unlocking opera-	a- Push and hold	Push twice
	tion		One short push
	Panic function	ON	OFF
Door lock (→P. 22, 594)	Speed-detecting auto- matic door lock func- tion	OFF	ON
	Opening driver's door unlocks all doors.	OFF	ON
	Shifting gears to P unlocks all doors.	ON	OFF
	Shifting gears to posi- tion other than P locks all doors.	ON	OFF
	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step

ltem	Function	Default setting	Customized setting
Trunk (→P. 26)	Power trunk opener and closer function	ON	OFF
Power win- dows (→P. 59)	Mechanical key linked operation	ON	OFF
	Mechanical key linked	Open and close	Open only
	operation		Close only
	Wireless remote con- trol linked operation	ON	OFF
	Linked entry operation	ON	OFF
	Mechanical key linked operation	ON	OFF
	Mechanical key linked	Open and close	Open only
	operation		Close only
Moon roof (→P. 61)	Linked operation of components when door key is used	Slide only	Tilt only
	Wireless remote con- trol linked operation	ON	OFF
	Linked operation of components when wireless remote con- trol used	Slide only	Tilt only
	Linked entry function	ON	OFF

6-2. Customization

ltem	Function	Default setting	Customized setting
Automatic light control system (→P. 138)	Light sensor sensitivity	Level 3	Level1to 5
	Time elapsed before headlights automati- cally turn off after	30 seconds	0 second
			60 seconds
	doors are closed		90 seconds
Lights (→P. 138)	Daytime running light system (U.S.A. only)	ON	OFF
Intuitive	Buzzer volume	Level 3	Level1to 5
parking assist-sensor (→P. 159)	Distance at which the front and back sensors detect an obstacle	Level 1	Level 2
	Time elapsed before	15 seconds	7.5 seconds
	lights turn off	10 30001103	30 seconds
Illumination (→P. 406)	Operation when the doors are unlocked	ON	OFF
	Operation after the engine switch is turned OFF	ON	OFF
	Footwell lighting	ON	OFF
	Shift lever lighting	ON	OFF
	Outer foot lights	ON	OFF
Seat belt reminder (→P. 572)	Vehicle speed linked seat belt reminder buzzer	ON	OFF

Multi-information display (\rightarrow P. 134)

Country	Available languages
U.S.A.	English and Spanish
Canada	English, French, German, Spanish and Italian