

1995 MY U.S.A. Maintenance Schedule

Chassis & Body

No.	Items	Service Intervals											Months	SC400 SC300	GS300	ES300	LS400
		x 1000 miles	1	7.5	15	22.5	30	37.5	45	52.5	60						
1	Brake linings/drums & pads/disks		I	I		I		I		I		I	I: Every 24 Months	X	X	X	X
2	Brake fluid (Clutch fluid if equipped)		I		I		I		I		I		R: Every 36 Months	X	X	X	X
3	Brake lines and hoses				I		I		I		I		I: Every 24 Months		X	X	X
4	Steering linkage & Boots				I		I		I		I		I: Every 24 Months		X	X	X
5	Rack & Pinon Assembly/Steering gear box		I		I		I		I		I		I: Every 24 Months		X	X	X
6	Ball joints & dust cover				I		I		I		I		I: Every 24 Months		X	X	X
7	Transmission Fluid				I		I		I		I		I: Every 24 Months	X	X	X	X
8	Front differential		I		I		I		I		I		I: Every 24 Months			X	
9	Rear differential oil		I		I		I		I		I		I: Every 24 Months	X	X		X
10	Body Inspection		I	I	I	I	I	I	I	I	I		I: Every 12 Months	X	X	X	X
11	Air conditioning filter			I	R	I	R	I	R	I	R		I: Every 12 Months R: Every 24 Months				X
12	Road Test		I	I	I	I	I	I	I	I	I		I: Every 12 Months	X	X	X	X
13	Charcoal Canister											I	I: Every 72 Months	X	X	X	X

I: Inspect and correct or replace as necessary **R:** Replace, change, tire rotation or lubricants

1995 MY U.S.A. Maintenance Schedule

Engine

No.	Items	Service Intervals										Months	GS400	GS300	SC400	SC300	ES300	LS400	
		x 1000 miles	1	7.5	15	22.5	30	37.5	45	52.5	60								
1	Timing Belt	Replace 90,000 miles										R: Every 72 Months							X
2	Valve Clearance										I	I: Every 48 Months	+	+	+	+	+	+	
3	Drive Belt	Inspect 60,000 miles and then every 15,000 miles										I: 48m after every 12 m	X	X	X	X	X	X	
4	Engine Oil		R	R	R	R	R	R	R	R	R	R: Every 6 Months	X	X	X	X	X	X	
5	Engine Oil Filter		R	R	R	R	R	R	R	R	R	R: Every 6 Months	X	X	X	X	X	X	
6	Engine Coolant							R				R: 36 Months then every 24 Months	X	X	X	X	X	X	
7	Exhaust Pipes & Mountings					I					I	I: Every 36 Months	X	X	X	X	X	X	
8	Air Cleaner Filter					R					R	R: Every 36 Months	X	X	X	X	X	X	
9	Fuel lines/connections, fuel tank vapor vent system hoses & fuel tank band					I					I	I: Every 36 Months	X	X	X	X	X	X	
10	Fuel tank cap gasket										R	R: Every 72 Months	X	X	X	X	X	X	
11	Spark Plugs										R	R: Every 72 Months	X	X	X	X	X	X	

I: Inspect and correct or replace as necessary **R:** Replace, change, tire rotation or lubricants

+ : Audible