

1997 MY U.S.A. Maintenance Schedule

Chassis & Body

No.	Items	Service Intervals										Months	GS300	ES300	LS400	SC300	SC400	LX450
		x 1000 miles	1	7.5	15	22.5	30	37.5	45	52.5	60							
1	Brake Linings/Drums & Pads/Disks			I		I		I		I	I: Every 12 Months	X	X	X	X	X	X	
2	Brake Fluid					R				R	R: Every 24 Months	X	X	X	X	X	X	
3	Brake Lines and Hoses			I		I		I		I	I: Every 12 Months	X	X	X	X	X	X	
4	Steering Linkage & Boots			I		I		I		I	I: Every 12 Months	X	X	X	X	X	X	
5	Rack & Pinon Assembly/Steering Gear Box			I		I		I		I	I: Every 12 Months	X	X	X	X	X	X	
6	Ball Joints & Dust Cover			I		I		I		I	I: Every 12 Months	X	X	X	X	X	X	
7	Drive Shaft Boots Retorque flange			I		I		I		I	I: Every 12 Months	X	X	X	X	X		
				T		T		T		T	t: Every 12 Months	X	X	X	X	X		
				I		I		I		I	I: Every 24 Months		X		X		X	
8	Transmission Fluid Other than T-IV T-IV			I		I		I		I	I: Every 24 Months	X		X		X		
				I		I		I		I	I: Every 24 Months	X		X		X		
9	Transfer Case Oil					I				I	I: Every 24 Months						X	
10	Front Differential			I		I		I		I	I: Every 12 Months		X				X	
11	Rear Differential Oil Other With LSD			I		I		I		I	I: Every 12 Months	X		X	X	X	X	
											I: Every 12Mo. R: Every 48Mo.							
12	Body Inspection	I		I		I		I		I	I: Every 12 Months	X	X	X	X	X	X	
13	Air Conditioning Filter			I	R	I	R	I	R	I	R	I: Every 6 Months R: Every 12 Months			X			
												R: Every 6 Months						
												R: Every 18 Months						
14	Tire Rotation		R	R	R	R	R	R	R	R	R: Every 6 Months	X	X	X	X	X	X	
15	Road Test	I	I	I	I	I	I	I	I	I	I: Every 6 Months	X	X	X	X	X	X	
16	Driveshaft Bushing Grease					R				R	R: Every 24 Months						X	
17	Lubricate Steering Knuckle			R		R		R		R	R: Every 48 Months						X	
18	Front Wheel Bearings					R				R	R: 24 Mo.						X	
19	Propeller Shaft Grease			R		R		R		R	R: Every 12 Months						X	
20	Propeller Shaft Bolt Torque	I		T		T		T		T	I: Every 12 Months						X	
21	Charcoal Canister		Required for vehicles in CA, MA & NY onl							I	I: Every 72 Months	X	X	X	X	X	X	

I: Inspect and correct or replace as necessary **R**: Replace, change, tire rotation or lubricants **T**: Re-Torque

+: If Equipped

1997 MY U.S.A. Maintenance Schedule

Engine

No.	Items	Service Intervals										Months	GS300	ES300	LS400	SC300	SC400	LX450
		x 1000 miles	1	7.5	15	22.5	30	37.5	45	52.5	60							
1	Timing Belt	Replace 90,000 miles										R: Every 72 Months			X		X	
2	Valve Clearance									I	I: Every 48 Months	+	+	+	+	+	+	
3	Drive Belt						I			I	I: 48m after every 12 m	X	X	X	X	X	X	
4	Engine Oil		R	R	R	R	R	R	R	R	R: Every 6 Months	X	X	X	X	X	X	
5	Engine Oil Filter		R	R	R	R	R	R	R	R	R: Every 6 Months	X	X	X	X	X	X	
6	Engine Coolant					R				R	R: Every 24 Months	X	X	X	X	X	X	
7	Exhaust Pipes & Mountings	I		I		I		I		I	I: Every 12 Months	X	X	X	X	X	X	
8	Air Cleaner Filter					R				R	R: Every 24 Months	X	X	X	X	X	X	
9	Fuel lines/connections, fuel tank vapor vent system hoses & fuel tank band					I				I	I: Every 24 Months	X	X	X	X	X	X	
10	Fuel tank cap gasket					I				I	I: Every 24 Months	X	X	X	X	X	X	
11	Spark Plugs					R				R	R: Every 24 Months						X	
										R	R: Every 48 months	X	X	X	X	X		

I: Inspect and correct or replace as necessary **R:** Replace, change, tire rotation or lubricants

+ : Audible