

## **Navigation System Installation Guide**





## 1. Replace the navigation DVD

- a. Turn the ignition switch to the "ACC" or "ON" position.
- b. Open the rear hatch.




- c. Open the deck board sub-assembly.
- d. Support the deck board via the supporting rod.







- e. Disengage the 2 claws.
- f. Remove the navigation ECU cover.
- g. Press the "PUSH" button and slide it to the left.
  This will open the dust cover and eject the DVD.
- h. Remove and discard the old DVD.




## **Navigation System Installation Guide**



j. Press the "PUSH" button and slide it to the right. This will close the dust cover





- k. Reinstall the navigation ECU cover.
- I. Return the support rod to the closed position.
- m. Close the deck board sub-assembly.
- 2. Verify the search area is set to the local area described in the navigation system owners manual.
- 3. Your navigation system will now update on its own.

