



Sanyo SCP-7050 - Sprint

Phone Pairing	Hands Free Calling	Transfer Single Contacts	Transfer Multiple Contacts	Auto Connect	Audio Transfer (To Phone)	Audio Transfer (To Car)	Auto-Answer Call	Incoming Caller ID Display	Signal Strength Display
YES	YES	YES	YES	YES	YES	YES	YES	YES	YES

Phone Software Version Evaluated: 1.002SP

Comment:

General Tips:

- The Phone Keys are located on the steering wheel (On-Hook and Off-Hook).
- Phone numbers may be programmed into the vehicle after transferring the number from the handset or entered manually.
- An outgoing call log will not be created in the navigation system when using the handset to dial a phone number.

Bluetooth Operation*

A) Pair Phone to Vehicle

- On the Steering Wheel -

1. Press the Off-Hook button

- On the Navigation System -

1. Select "Settings"
2. Select "Bluetooth"
3. Select "Register"

- On the Phone -

1. Select "Menu"
2. Select "Tools"
3. Select "Bluetooth"
4. Select "Add New"
5. Select "Search"
6. Select "Yes" (If prompted)
7. Scroll to and Select "Handsfree"
8. Select "Add to Trusted"
9. Enter passkey shown on Handsfree display
10. Select "OK" (twice)
11. Press "Connect"

B) Transfer a Phone Number from Phone to Vehicle

- On the Steering Wheel -

1. Press the Off-Hook button

- On the Navigation System -

1. Select "Settings"
2. Select "Phonebook"
3. Select "Transfer Data"
4. Select desired Group
5. Select whether you wish to "Add" or "Overwrite"

- On the Phone -

1. Select "Menu"
2. Select "Tools"
3. Select "Bluetooth"
4. Scroll to "Handsfree"
5. Select "Options"
6. Select "Send Item"
7. Select "Contacts"
8. Select "Yes" (If prompted)
9. Select either "All" or "Select"
10. Select "Send"

C) Transfer a Phone Number from Vehicle Phonebook to Vehicle "Speed Dial"

- On the Steering Wheel -

1. Press the Off-Hook button

- On the Navigation System -

1. Select "Settings"
2. Select "Speed Dial"
3. Select the desired phone number to be programmed
4. Select the desired location to store the number
5. Repeat this procedure to transfer additional phone numbers

D) Make a "Speed Dial" Phone Call from the Vehicle

- On the Steering Wheel -

1. Press the Off-Hook button

- On the Navigation System -

1. Select "Speed Dial"
2. Select the entry you wish to dial

Note: If the vehicle is in motion, pressing the Off-Hook steering wheel button will transition directly to the "Speed Dial" screen.