


REAR SIDE MARKER LAMP LENS LH REPLACEMENT

65035-02

HINT:

COMPONENTS: See page 65-5

1. REMOVE TONNEAU COVER STOPPER SUB-ASSY LH (See Page 76-6)
2. REMOVE TONNEAU COVER STOPPER SUB-ASSY RH (See Page 76-6)
3. REMOVE REAR FLOOR FINISH PLATE (See Page 76-6)
4. REMOVE LUGGAGE COMPARTMENT FLOOR MAT (See Page 76-6)
5. REMOVE LUGGAGE COMPARTMENT TRIM COVER LH (See Page 76-6)
6. REMOVE LUGGAGE COMPARTMENT TRIM COVER RH (See Page 76-6)
7. REMOVE SPARE WHEEL COVER ASSY (See Page 76-6)
8. REMOVE TOOL BOX COVER (See Page 76-6)
9. REMOVE LUGGAGE COMPARTMENT TRIM COVER SUB-ASSY REAR (See Page 76-6)
10. REMOVE TONNEAU COVER ASSY (See Page 76-6)
11. REMOVE LUGGAGE COMPARTMENT TRIM COVER INNER LOWER (See Page 76-6)
12. REMOVE LUGGAGE COMPARTMENT TRIM COVER FRONT (See Page 76-6)
13. REMOVE LUGGAGE COMPARTMENT TRIM COVER SIDE LH (See Page 76-6)
14. REMOVE LUGGAGE COMPARTMENT TRIM COVER SIDE RH (See Page 76-6)
15. REMOVE REAR BUMPER COVER (See page 76-6)



16. REMOVE REAR SIDE MARKER LAMP LENS LH
 - (a) Remove the screw.
 - (b) Remove the rear side marker lamp lens assy.
 - (c) Remove the bulb socket and rear side marker lamp lens LH.