


G ELECTRICAL WIRING ROUTING

Position of Parts in Body

[LHD]



A29 ABS Speed Sensor Rear LH
 A30 ABS Speed Sensor Rear RH
 A31 Auto Antenna Control Relay

B 8 Back-Up Light LH
 B 9 Back-Up Light RH

C11 Cellular Phone (Hand Set)

D 6 Door Courtesy Light LH
 D 7 Door Courtesy Light RH
 D 8 Door Courtesy SW LH
 D 9 Door Courtesy SW RH
 D10 Door Key Lock and Unlock SW LH
 Door Lock Motor LH
 Door Unlock Detection SW LH
 D12 Door Lock Motor LH
 Door Unlock Detection SW LH
 Double Lock Motor LH
 Double Lock Position SW LH
 D13 Door Lock Motor RH
 Door Unlock Detection SW RH
 Double Lock Motor RH
 Double Lock Position SW RH

D15 Door Lock Control SW RH
 D17 Door Lock Motor RH
 Door Unlock Detection SW RH
 D18 Door Side Airbag Sensor LH
 D19 Door Side Airbag Sensor RH
 D20 Door Speaker LH (Squawker and Tweeter)
 D21 Door Speaker RH (Squawker and Tweeter)
 D22 Driver Door ECU
 D23 Driver Door ECU
 D24 Driver Door ECU
 D25 Driving Position Memory SW LH
 D26 Driving Position Memory SW RH

F 15 Fuel Lid Opener Motor
 F16 Fuel Pump
 Fuel Sender (Main)
 F17 Fuel Sender (Sub)

H18 Height Control Sensor (Rear)
 H19 High Mounted Stop Light

I 19 Inner Mirror
 Wireless Door Lock Control Receiver