


Position of Parts in Body <RHD>




























Position of Parts in Body <RHD>

---

- N 4 Navigation ECU
- N 5 Navigation ECU
- N 6 Noise Filter (Rear Window Defogger)
- N 7 Navigation Amplifier
- N 8 Navigation ECU
  
- P 8 Package Tray Motor
- P 9 Passenger Door ECU
- P 10 Passenger Door ECU
- P 11 Passenger Door ECU
- P 12 Personal Light , Microphone (Navigation)
- P 13 Power Window Control SW LH
- P 16 Power Window Motor LH
- P 17 Power Window Motor RH
- P 18 Pretensioner LH
- P 19 Pretensioner RH
- P 43 Power Window Master SW
  
- Q 1 Quarter Power Window Motor LH
- Q 2 Quarter Power Window Motor RH
  
- R 7 Rear Combination Light LH
- R 8 Rear Combination Light RH
- R 9 Rear Fog Light LH
- R 10 Rear Fog Light RH
- R 11 Rear Speaker LH
- R 12 Rear Speaker RH
- R 13 Rear Window Defogger
- R 14 Rear Window Defogger
- R 15 Remote Control Mirror LH
- R 16 Remote Control Mirror RH
- R 17 Roof Drive Motor LH
- R 18 Roof Drive Motor RH
- R 19 Roof Lock Motor

Position of Parts in Body <RHD>



Position of Parts in Body <RHD>

---

R 17  
Gray



R 18  
Gray



R 19  
White

