


[LHD]



A29 ABS Speed Sensor Rear LH
A30 ABS Speed Sensor Rear RH
A31 Auto Antenna Control Relay

B 8 Back-Up Light LH
B 9 Back-Up Light RH

C 11 Cellular Phone (Hand Set)

D 6 Door Courtesy Light LH
D 7 Door Courtesy Light RH
D 8 Door Courtesy SW LH
D 9 Door Courtesy SW RH
D10 Door Key Lock and Unlock SW LH
Door Lock Motor LH
Door Unlock Detection SW LH
D12 Door Lock Motor LH
Door Unlock Detection SW LH
Double Lock Motor LH
Double Lock Position SW LH
D13 Door Lock Motor RH
Door Unlock Detection SW RH
Double Lock Motor RH
Double Lock Position SW RH

D15 Door Lock Control SW RH
D17 Door Lock Motor RH
Door Unlock Detection SW RH
D18 Door Side Airbag Sensor LH
D19 Door Side Airbag Sensor RH
D20 Door Speaker LH (Squawker and Tweeter)
D21 Door Speaker RH (Squawker and Tweeter)
D22 Driver Door ECU
D23 Driver Door ECU
D24 Driver Door ECU
D25 Driving Position Memory SW LH
D26 Driving Position Memory SW RH

F 15 Fuel Lid Opener Motor
F 16 Fuel Pump
Fuel Sender (Main)
F 17 Fuel Sender (Sub)

H18 Height Control Sensor (Rear)
H19 High Mounted Stop Light

I 19 Inner Mirror
Wireless Door Lock Control Receiver