

Oil Specification Chart -

<u>2010 MY</u>		<u>2011 MY</u>		<u>2012 MY</u>	
RX 350	0W-20	RX 350	0W-20	RX 350	0W-20
RX 450h	0W-20	RX 450h	0W-20	RX 450h	0W-20
HS 250h	0W-20	HS 250h	0W-20	HS 250h	0W-20
GX 460	0W-20	GX 460	0W-20	GX 460	0W-20
ES 350	5W-30	ES 350	5W-30	ES 350	5W-30
GS 350	5W-30	GS 350	5W-20 or 0W-20	GS 350	No GS in 2012
LS 460	5W-20 or 0W-20	LS 460	5W-20 or 0W-20	LS 460	5W-20 or 0W-20
LS 600hl	5W-20 or 0W-20	LS 600hl	5W-20 or 0W-20	LS 600hl	5W-20 or 0W-20
IS 250	5W-30	IS 250	0W-20	IS 250	0W-20
IS 350	5W-30	IS 250C	0W-20	IS 350	0W-20
LX 570	5W-20 or 0W-20	IS 350	0W-20	LX 570	No GX in 2012
SC 430	5W-20 or 0W-20	IS 350C	0W-20	IS-F	5W-30
IS-F	5W-30	LX 570	5W-20 or 0W-20	LFA	5W-50
		IS-F	5W-30	CT 200h	0W-20
		CT 200h	0W-20		

<u>2013 MY</u>		<u>2014 MY</u>		<u>2015 MY</u>	
RX 350	0W-20	RX 350	0W-20	RX 350	0W-20
RX 450h	0W-20	RX 450h	0W-20	RX 450h	0W-20
GX 460	0W-20	GX 460	0W-20	GX 460	0W-20
ES 350	0W-20	ES 350	0W-20	ES 350	0W-20
GS 350	0W-20	GS 350	0W-20	GS 350	0W-20
LS 460	5W-20 or 0W-20	LS 460	0W-20	LS 460	0W-20
LS 600hl	5W-20 or 0W-20	LS 600hl	0W-20	LS 600hl	0W-20
IS 250	0W-20	IS 250	0W-20	IS 250	0W-20
IS 250C	0W-20	IS 250C	0W-20	IS 250C	0W-20
IS 350	0W-20	IS 350	0W-20	IS 350	0W-20
IS 350C	0W-20	IS 350C	0W-20	IS 350C	0W-20
LX 570	0W-20	LX 570	0W-20	LX 570	0W-20
IS-F	5W-30	IS-F	5W-30	CT 200h	0W-20
CT 200h	0W-20	CT 200h	0W-20	NX 200t	0W-20
				NX 300h	0W-20
				RC 350	0W-20
				RC-F	5W-30