

# Accelerator Pedal Sensor Assembly Service Precaution

**Service Category** Engine/Hybrid System

**Section** Engine Control

**Market** USA

Lexus Supports  
ASE Certification 

## Applicability

| YEAR(S)     | MODEL(S)  | ADDITIONAL INFORMATION |
|-------------|---|------------------------|
| 2001 – 2013 | CT200H, ES300,<br>ES300H, ES330,<br>ES350, GS300,<br>GS350, GS430,<br>GS450H, GS460,<br>GX460, GX470,<br>HS250H, IS F,<br>IS250, IS250C, IS350,<br>IS350C, LFA, LS430,<br>LS460, LS600H,<br>LX470, LX570, RX330,<br>RX350, RX400H,<br>RX450H, SC430 |                        |

## Introduction

This bulletin provides a service precaution related to the accelerator pedal sensor assembly during inspection, removal, and installation.

## Warranty Information

| OP CODE | DESCRIPTION                | TIME | OFD | T1 | T2 |
|---------|----------------------------|------|-----|----|----|
| N/A     | Not Applicable to Warranty | –    | –   | –  | –  |


## Accelerator Pedal Sensor Assembly Service Precaution

### Service Precaution

**PRECAUTION**

This accelerator pedal does not require lubrication. Do NOT apply oil or other lubrication to the accelerator pedal sensor assembly. If applied, the accelerator pedal sensor assembly must be replaced.

Figure 1.



|   |                                   |
|---|-----------------------------------|
| 1 | Accelerator Pedal Sensor Assembly |
|---|-----------------------------------|