



**Technical Service
Information Bulletin**

March 1, 2006

Title:

**POWER SYSTEM INITIALIZATION
DURING PDS**

Models:

'06 All Lexus Models

REVISED

PD009-06

PRE-DELIVERY SERVICE

TSIB REVISION NOTICE:

- **March 8, 2006:** The Power System Initialization Table has been updated to include TSIB references for the power window and sliding roof for the GX 470. Previous versions of this TSIB should be discarded.

Introduction The following is a list of the vehicle systems (Power Window, Sliding Roof, Tire Pressure Warning System, etc.) that need initialization during Pre-Delivery Service (PDS) and the TSIB numbers containing details on initializing each specific system.

NOTE:

Items in **RED** also need to be initialized any time the battery has been disconnected.

Applicable Vehicles

- All **2006** model year **Lexus** vehicles.

Power System Initialization Table

MODEL NAME	INITIALIZATION SYSTEM ITEMS							
	COMPASS	POWER WINDOW	POWER BACK DOOR	SLIDING ROOF	TIRE PRESSURE WARNING SYSTEM		VGRS	SEAT
					DIRECT	INDIRECT		
ES 330	PD034-05	-	-	PD033-05	-	-	-	-
GS 300/430	PD001-05	PD007-05	-	PD003-05	PD008-05	-	PD009-05*	PD004-05
GX 470	PG017-02	PD018-05	-	PG016-02	PD005-03	-	-	-
IS 250/350	PD040-05	PD043-05	-	-	PD044-05	-	-	-
LS 430	PG009-01	-	-	-		PD022-05	-	-
LX 470	PG007-00	-	-	-	PD021-05	-	PG011-02	-
RX 330	PD028-05	PD026-05	PD031-05	PD027-05	-	PD030-05	-	-
RX 400h	PD017-05	PD016-05	PD014-05	PD013-05	-	-	-	-
SC 430	PG010-01	-	-	-	PG006-01	-	-	PG005-03

* Initialization of VGRS applies ONLY to 2006 model year GS 430 vehicles.

Warranty Information

OP CODE	DESCRIPTION	TIME	OFF	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-

