



STARTER ASSY COMPONENTS

1904A-01




Y


B12251



B12329



Magnetic Switch Assembly



◆ Non-reusable part

B12317