
Engine Wire
Engine Wire
RH Exhaust Manifold
Engine Wire
◆ Gasket
RH Exhaust Manifold Stay
x 6
49 (500, 36)
Camshaft Timing Oil Control Valve
Cylinder Head Rear Plate
◆ O–Ring
PS Pump Bracket
Camshaft Position Sensor
43 (440, 32)
◆ O–Ring
◆ O–Ring
◆ O–Ring
Gasket
No.3 Timing Belt Cover
Water Inlet Pipe
Collar
Bushing
◆ O–Ring
Camshaft Position Sensor
x 6
Engine Wire
Oil Dipstick Guide
◆ Gasket
x 6
LH Exhaust Manifold Stay
49 (500, 36)
◆ O–Ring
LH Exhaust Manifold
N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non–reusable part
A06660