

Category	Item Select	Default	New Value	Description	Options
Wireless Door Lock	OPEN DOOR WARNING	ON		ON/OFF of 10 second buzzer if door is open when locking with wireless transmitter	ON/OFF
Wireless Door Lock	WIRELESS BUZZ VOLUME	MID2		Adjusts the volume of the wireless buzzer	OFF/MIN/MID1/MID2/MID3/MAX
Wireless Door Lock	WIRELESS OPERATION	ON		ON/OFF of the wireless door lock function	ON/OFF
Wireless Door Lock	CAR FINDER	ON		ON/OFF of the car finder function which lights up all turn signal lights once when lock button is pressed on transmitter while vehicle doors are locked and closed	ON/OFF
Wireless Door Lock	ALARM FUNCTION	ON		ON/OFF of panic function if transmitter button is pressed for 1.5 seconds	ON/OFF
Wireless Door Lock	INT/LGT ON/UNLOCK	ON		ON/OFF of interior lights when vehicle is unlocked with transmitter	ON/OFF
Wireless Door Lock	UNLOCK/20PER	ON		ON Pressing transmitter unlock button once will unlock drivers door pressing twice will unlock all doors OFF Pressing transmitter button once makes all doors unlock.	ON/OFF
Wireless Door Lock	TRUNK LID OPER	ON		OFF Transmitter will not open trunk	ON/OFF
Wireless Door Lock	AUTO LOCK DELAY	0.8PR		0.8PR Trunk button must be pressed for 0.8 seconds-to open trunk 1TIME Trunk button must be pressed once to open trunk 2TIME Trunk button must be pressed twice to open trunk	OFF/0.8PR/1TIME/2TIME
Door Lock	UNLOCK/PARK	OFF		ON/OFF of door auto unlock when vehicle is stopped and shifted into Park	ON/OFF
Door Lock	ALL UNLOCK/OPN-CL	OFF		ON/OFF of door auto unlock for all doors when drivers door opens within 10 seconds of turning the ignition key from ON to OFF	ON/OFF
Door Lock	UNLOCK/KEY TWICE	ON		ON When unlocking the drivers door one turn of the key will unlock drivers door only two turns will unlock all doors OFF When unlocking drivers door one turn will unlock all doors	ON/OFF
Door Lock	ANSWER BACK	HAZARD		HAZARD: Hazard lights will blink once when transmitter is used to lock vehicle and twice when unlocking the vehicle providing the doors hood and trunk are dosed	HAZARD/OFF

Category	Item Select	Default	New Value	Description	Options
Security	PASSIVE MODE	OFF		ON/OFF of automatic activation of the security system 30 seconds after key is removed from ignition and doors are dosed. Upon reentry driver has 15 seconds to: 1) insert key into the ignition front door or trunk 2) use transmitter to open vehicle	ON/OFF
Security	UP/DOOR KEY	ON		ON/OFF: Windows will roll up when key is locking drivers door and held for 1.5 seconds with the ignition off	ON/OFF
Power Window	DOWN/DOOR KEY	ON		ON/OFF: Windows will roll down when key is unlocking drivers door and held for 1.5 seconds with the ignition off	ON/OFF
Power Window	DOWN/WIRELESS	ON		ON/OFF: Windows will roll down when transmitter unlock button is held for 1.5 seconds with the ignition off	ON/OFF
Wiper(LS400)	REWIPE FUNCTION	ON		ON/OFF of delayed rewipe of windshield 15-30 seconds after washer is used	ON/OFF
Wiper(LS400)	SPEED MODE	ON		ON/OFF of intermittent wiper speed change as vehicle comes to a stop with the wipers set on LOW	ON/OFF
Illuminated Entry	LIGHTING TIME	15S		Delay of interior light dimming function. Interior lights will dim quickly if ignition is ON	7.5S/15S/30S
Illuminated Entry	I/L ON /UNLOCK	ON		ON/OFF of interior light up when unlocking door using door lock cylinder. Regardless of this setting interior lights will still light up when interior light switch is in the door position and door is opened.	ON/OFF
Warning	LIGHT REMIND	OFF		ON/OFF of headlight reminder buzzer	ON/OFF
Warning	KEY REMIND SOUND	NORMAL		Frequency of key reminder buzzer	LOW/NORM/HIGH
Warning	KEY REMIND VOLUME	LARGE		Volume of key reminder buzzer	SMALL/MED/LRG
Warning	LIGHT OFF DELAY	30S		Delay time for headlight turnoff to specified setting	OFF/30S/60S/90S
Warning	LIGHT CTRL TYPE	CURRENT		OLD: 6 second automatic headlight ON delay 8 second headlight OFF delay CURRENT: 15 second delay for automatic headlight ON or OFF	CURRENT/OLD
Light Control	SENSITIVITY	NORMAL		djusts the sensitivity of the automatic headlight illumination system	DARK2/DARK1/NORMAL/LIGHT1/LIGHT2

Category	Item Select	Default	New Value	Description	Options
Light Control	DISP EX ON SEN	NORMAL		Adjusts the brightness of indicator lights (Shift Taillight Headlight Cruise and Power Mode indicators) when headlights are ON	DARK2/DARK1/NORMAL/LIGHT1/LIGHT2
Light Control	DISP EX OFF SEN	ON		Adjusts the brightness of indicator lights (Shift Taillight Headlight Cruise and Power Mode indicators) when headlights are OFF	DARK2/DARK1/NORMAL/LIGHT1/LIGHT2
Tilt & Telescope	AUTO TILT AWAY	ON		ON/OFF of auto away/return function	ON/OFF
Sliding Roof	OPEN/DOOR KEY	ON		Links sliding roof to DOWN/DOOR KEY function when door is unlocked for 1.5 seconds	ON/OFF
Sliding Roof	CLOSE/DOOR KEY	ON		Links sliding roof to UP/DOOR KEY function when door is locked for 1.5 seconds	ON/OFF
Sliding Roof	OPEN/WIRELESS	ON		Links sliding roof to DOWN/WIRELESS function when transmitter unlock button is pressed for 1.5 seconds	ON/OFF
Sliding Roof	DOOR KEYOPER	SLIDE		Changes operation of sliding roof when using key to open or close roof	SLIDE/TILT
Sliding Roof	WIRELESS OPER	SLIDE		Changes operation of sliding roof when using transmitter to open roof	SLIDE/TILT
Air Conditioner	AIR INLET MODE	AUTO		AUTO : Will automatically change air inlet to RECIRCULATE when A/C is turned ON MANUAL: Will not change air inlet when A/C is turned ON	AUTO/MANUAL
Air Conditioner	COMPRESSOR MODE	AUTO		AUTO : Will automatically turn ON A/C if AUTO button is pressed when blower is ON MANUAL: Driver must turn ON the A/C when Auto button is pressed	AUTO/MANUAL
Air Conditioner	COMPRS/DEF OPER	LINK		Link : A/C will turn ON when Defroster is ON NORMAL: A/C must be manually activated when Defroster is turned ON	LINK/NORMAL
Air Conditioner	AIR INLET OPER	LINK		Link: In the event of A/C malfunction air inlet will change to OUTSIDE. NORMAL: Air inlet will not change.	LINK/NORMAL