


# BODY DIMENSION DRAWINGS

## ENGINE COMPARTMENT

(Three-Dimensional Distance)



Vehicle Dimensions

A-L or a-l	A-M or a-m	A-m or a-M	B-c or b-C	B-f	b-F	g-H	J-j
298 (11.73)	624 (24.57)	1,607 (63.27)	1,374 (54.09)	1,078 (42.44)	1,075 (42.32)	946 (37.24)	1,037 (40.83)

Height from Imaginary Standard Line

A,a	C,c	K,k
706 (27.80)	823 (32.40)	639 (25.16)

HINT: For symbols, capital letters indicate right side of vehicle, small letters indicate left side of vehicle (seen from rear).

mm (in.)

Symbol	Name	Hole dia.	H, h	Radiator support standard hole	ø10 (0.39)
A, a	Front fender installation nut	M6 (0.24)	I, i	Hood lock support installation nut	M6 (0.24)
B, b	Front spring support hole-inner	ø12.5 (0.492)	J, j	Front bumper reinforcement installation nut	M10 (0.39)
C, c	Hood hinge installation nut	M8 (0.31)	K, k	Radiator upper support installation nut	M6 (0.24)
D, d	Cowl panel center mark	—	L, l	Front fender installation nut	M6 (0.24)
E, e	Front side member standard hole	ø18 (0.71)	M, m	Front fender installation nut	M6 (0.24)
F, f	Front side member standard hole	RH: ø16 (0.63) LH: ø13 (0.51)	N, n	Front wheel opening No.1 extension installation nut	M6 (0.24)
G, g	Radiator upper support installation nut	M6 (0.24)	O, o	Front fender apron standard hole	ø10 (0.39)