



(b) Place supplied oil impregnate rubber bushings onto the sway bar.

(1) Cut in bushing will face upward and forward. (Fig 2-2)

(c) Install the front sway bar brackets on the vehicle with the 4 bolts. (Fig 2-3)

Torque: 78 N·m (795 kgf·cm, 57 ft·lbf)

(d) Install the front stabilizer link assemblies with the 4 nuts. (Fig 2-4)

(1) If the ball joint turns together with the nut, use a hexagon (6 mm) wrench to hold the stud.

Torque: 84 N·m (856 kgf·cm, 62 ft·lbf)

(e) Raise the front of the sub frame back into contact with the bottom of the vehicle.

(f) Tighten fasteners: (Fig 2-5)

A: Torque: 167 N·m (1,700 kgf·cm, 123 ft·lbf)

B: Torque: 165 N·m (1,680 kgf·cm, 122 ft·lbf)

C: Torque: 50 N·m (510 kgf·cm, 37 ft·lbf)